



KYOCERA Document Solutions
A.B.N. 77 003 852 444
Level 3, 6-10 Talavera Road
North Ryde NSW 2113
TEL: (02) 9888 9988
Fax: (02) 9888 9588
SERVICE: 13 5962
www.kyoceradocumentsolutions.com.au




The FS-1030 / 1130 /1035 / 1135 MFP uses an electronic counter to record the copy counts. This can be read off the LCD display.

Please use the following steps to check the electronic copy count.


Step 1 Press the System Menu/Counter button on the Operator Panel.




Step 2 Press the **UP** or **DOWN** button on the printer front panel to select **Counter**.
Press **OK**.




Step 3 Press the **UP** or **DOWN** button on the printer front panel to select **Printed Pages**.
Press **OK**.



Step 4 Select by Function, Press **OK**.



Step 5 Press the **LEFT** or **RIGHT** key to check the **Count**.



Step 6 After completing checking the count, press the **OK** key. The screen returns to the menu page.