



KYOCERA Document Solutions
A.B.N. 77 003 852 444
Level 3, 6-10 Talavera Road
North Ryde NSW 2113
TEL: (02) 9888 9988
Fax: (02) 9888 9588
SERVICE: 13 5962
www.kyoceradocumentsolutions.com.au




The FS-C5400DN uses an electronic counter to record the copy counts. This can be read off the LCD display.

Please use the following steps to check the electronic counts.

Step 1 Press the MENU button on the printer front panel

Step 2 Press the **UP** or **DOWN** button on the printer front panel to select Counter.

Step 3 Press **OK**. The **Counter** menu appears showing a list of available options.



Step 4 In the Counter menu screen,
Press the **UP** or **DOWN** to select **Colour** or **Black & White**.
Press **OK**.

The screen showing the total number of **Colour** pages printed

Color:	↕ OK
Total	17000
A4	2000
B5	1000

The screen showing the total number of **Black & White** pages printed

Black & White:	↕ OK
Total	17000
A4	2000
B5	1000

Step 5 Pressing **OK** returns you to the menu.