



KYOCERA Document Solutions
A.B.N. 77 003 852 444
Level 3, 6-10 Talavera Road
North Ryde NSW 2113
TEL: (02) 9888 9988
Fax: (02) 9888 9588
SERVICE: 13 5962
www.kyoceradocumentsolutions.com.au




The FS-C8500DN uses an electronic counter to record the copy counts. This can be read off the LCD display.

Please use the following steps to check the electronic counts.


Step 1 Press the **MENU** button on the printer front panel

Step 2 Press the **UP** or **DOWN** button on the printer front panel to select Counter.

Step 3 Press **OK**. The **Counter** menu appears showing a list of available options.



Step 4 Press the **UP** or **DOWN** until **> Colour** appears.
The total number of **Colour** Printed Pages is displayed



Press the **UP** or **DOWN** until > **Black & White** appears.
The total number of **Black & White** Printed Pages is displayed

Black & White:	↕ OK
Total	17000
A3	2000
A4	1000

Step 5 Press **OK** returns you to the counter menu.